Preferable fits of the hole-basis system (ISO 286-1:2010)

Basic	Tolerance classes for shafts																	
Hole	Clearance Fits							Transition Fits				Interference Fits						
H6						g5	h5	js5	k5	m5		n5	p5					
H7					f6	g6	h6	js6	k6	m6	n6		p6	r6	s6	t6	u6	x6
				e7	f7		h7	js7	k7	m7					s7		u7	
H8			d8	e8	f8		h8											
H9			d8	e8	f8		h8											
H10	b9	c9	d9	e9			h9											
H11	b11	c11	d10				h10											

Preferable fits of the shaft-basis system (ISO 286-1:2010)

Basic	Tolerance classes for holes																	
Shaft	Clearance Fits							Transition Fits				Interference Fits						
h5						G6	H6	JS6	K6	M6		N6	P6					
h6					F7	G7	H7	JS7	K7	M7	N7		P7	R7	S7	T7	U7	X7
h7				E8	F8		H8											
h8			D9	E9	F9		H9											
				E8	F8		H8											
			D9	E9	F9		H9											
h9	B11	C10	D10				H10											